

Hooks

How to order a hook:

1. Identify hoist series and capacity for which hooks are to be used.
2. Determine chain type and required hook opening.
3. Determine chain type or latch/gate replacement.
4. Select hook and the applicable part number.



WARNING: Failure to use the proper hook may result in operator injury or damage to the workpiece.

Hoist Capacity (lbs.)	*Hook Type	Hook Opening (inches)	Link Chain			Roller Chain			Latch/Gate Replacement		
			Upper Hook	Lower Hook	Lower Hook Asm.	Upper Hook	Lower Hook	Lower Hook Asm.	Crosby (old)	Crosby (new)	Bullard Gate Kit
Hoist Series 7											
275	STD	7/8			532361				507523	542390	
275	STD	15/16	540831						540832	540832	
Hoist Series K5											
550/1100	STD	1-1/8	523386			523386			A27352		
550/1100	STD	15/16		530222			530222		A27305	540832	
550/1100	B	1-1/4	526329			526329					526567
550/1100	B	1-1/32		529455			529455				526566
2200	STD	1-1/8	523385	523443	523390	523385	A26061	534932	A27352	542388	
2200	B	1-1/4	526331	526327	526326	526331	A29919	535092			526567
Hoist Series K1											
2200	STD	1-11/32	528710	531008	531852				507938	542386	
2200	B	1-1/2	531763	531766	531768						528618
3300	STD	1-11/32	528710	531008	531853				507938	542386	
3300	B	1-1/2	531763	531766	531769						528618
4400	STD	1-11/32	528710	531008	531854				507938	542386	
4400	B	1/1/2	531763	531766	531770						526618
6600	STD	1-11/16	530232	530228	530371				516719	542389	
6600	B	1-7/8	531764	531767	531773						528618
8800	STD	1-11/16	530232	530228	530362				516719	542389	
8800	B	1-7/8	531764	531767	531774						528618
Hoist Series P1											
300/500/1000	STD**	7/8		539224					507523	542390	
300/500/1000	STD	15/16	539500	A20705S		539500	A10781S		A27305	540832	
500	SR	15/16	539557			539557	A17247S		A27305		
300/500/1000	B	1-1/32	539558	A29935		539558	A29934				526566
2000	STD	1-1/8	500374	A26061	AA27103	500374	A26061	AA26061	A27352	542388	
1000	SR	1-1/8							A27352	542406	
2000	B	1-1/4	505109	A29919	AA30728	505109	A29919	AA29919			526567
Hoist Series P2											
1100/2200	STD	1-1/8	541145	532074	533196	541145	532074	533197	A27352	542388	
1100/2200	B	1/14	541146	533167	533192	533163	533167	533193			526567
1500	SR	1-1/8	541189	532146	533490				A27352	542406	
1500	B/SR	1-1/4	533188	533170	533194						526567
3000	SR	1-11/32	542355	532194	532156				507938	542407	
3000	B/SR	1-1/2	542356	533156	533157						528618
4400	STD	1-11/32	542378	532177	532155	532164	532177	532162	507938	542386	
4400	B	1-1/2	542342	533153	533154	533160	533155	533155			528618
Hoist Series P3											
2200	STD	1-11/32	531129						507938	542386	
2200	STD	1-11/32		531008					507938	542386	
2200	B	1-1/2	537266	531766	531768						528618
4300	STD	1-11/32	531129	531008	531776				507938	542386	
4300	B	1-1/2	537266	531766							528618
8000	STD	1-11/16	531874	530228	531085				516719	542389	
8000	B	1-7/8	537266	531767	531775						528618

*B = Bullard; SR = Spark Resistant; STD = Standard

**Trolley Mounted Only